

Read these important safety instructions:

- **CONSIDER YOUR WORK AREA ENVIRONMENT.** Don't use Blower in damp or wet locations. Don't operate Blower in presence of flammable liquids, gases like gasoline or other fuels, lighter fluid, cleaners, oil-based paints, natural gas, hydrogen, coal dust, magnesium dust, grain dust, or explosive dust like gun powder. Do not use or store near hazardous or toxic materials.
 - **USE SAFETY GLASSES.** Also use face or dust mask if work area is dusty. The operation of any utility blower can result in foreign objects being blown into the eyes, which can result in severe eye damage. Always wear safety goggles complying with ANSI Z87.1.
 - **DON'T ABUSE CORD.** Never pull the Blower cord or yank it to disconnect from receptacle. To unplug, grasp the plug, not the cord. Keep cord away from heat, oil, and sharp edges. Do not pull or carry by cord, use cord as handle, close a door on cord, or pull cord around sharp edges or corners.
 - **SECURE BLOWER** if used in an unstable area such as on a moving RV, etc.
 - **MAINTAIN BLOWER.** Keep Blower, motor and blower wheel clean. For safer operation, follow instructions for attaching accessories. Keep handle dry, clean and free from oil, grease and water.
 - **DISCONNECT BLOWER** when not in use, before servicing, and when attaching accessories. Turn off air mover before unplugging.
- NEVER** stick a screwdriver or any other object into the ventilation openings or air intake areas. Do not operate with any ventilation openings blocked; keep free of dust, lint, hair or anything that may reduce airflow. Keep hair, loose clothing, fingers and all parts of body away from openings and moving parts. DO NOT restrict air intake.
- **INSPECT FOR DAMAGE** before using Blower. Determine before use if it will operate properly. Check for alignment and/or binding of the motor and blower wheel. Inspect cord periodically for damage. Check the switch by turning the Blower on and off while unit is plugged in.
 - **RETURN BLOWER** for repair or to replace damaged parts if any of them are found to be broken or if your Blower is inoperative. The Blower products may only be serviced and repaired by the official **Call 1-800-433-162 for instructions on how to send your Blue Blower in for repair or to receive your repair authorization code.**

Send all BLOWERS to be repaired to the location listed below. Make sure you include your name, address, phone number, the problem encountered and your repair authorization code.

**The address is as follows:
Ventamatic Ltd
100 Washington
Mineral Wells, TX 76068
1-800-433-1626**